

INSTALLATION MANUAL

AIR CONDITIONER

Please read this installation manual completely before installing the product.
Installation work must be performed in accordance with the national wiring standards by authorized personnel only.
Please retain this installation manual for future reference after reading it thoroughly.

Cable Assembly
PZCWRCG3



P/NO : 3828A20860M


www.lg.com

TABLE OF CONTENTS

- Part Description3
- Installation Guide4
 - Wiring diagram to use Group control.....4
 - Installing step4

Part Description

This Accessory is used to help Wired Remote group control



- 1** Cable assembly for indoor units: 1EA
- 2** Cable assembly for Connecting indoor to indoor: 1EA

Please Connect wire **1**, **2**

Note :

- 1** Cable assembly for indoor units
- 2** Cable assembly for Connecting indoor to indoor
 - Please connect cable assembly **1** with already connected indoor unit



